#### STATUTORY INSTRUMENTS

## 1996 No. 913

# The Offshore Installations and Wells (Design and Construction, etc.) Regulations 1996

### PART IV

#### WELLS

#### Design with a view to suspension and abandonment

**15.** The well-operator shall ensure that a well is so designed and constructed that, so far as is reasonably practicable—

- (a) it can be suspended or abandoned in a safe manner; and
- (b) after its suspension or abandonment there can be no unplanned escape of fluids from it or from the reservoir to which it led.

**Changes to legislation:** There are currently no known outstanding effects for the The Offshore Installations and Wells (Design and Construction, etc.) Regulations 1996, Section 15.