
STATUTORY INSTRUMENTS

2007 No. 3468

The Air Navigation (Overseas Territories) Order 2007

PART XVII

GENERAL

Power to prevent aircraft flying

141.—(1) If it appears to the Governor or an authorised person that any aircraft is intended or likely to be flown—

- (a) in such circumstances that any provision of article 3, 5, 7, 20, 21, 56, 57, 58, 64, 127(2), 135, 137 or 138 would be contravened in relation to the flight;
- (b) in such circumstances that the flight would be in contravention of any other provision of this Order or of any regulations made thereunder, and be a cause of danger to any person or property whether or not in the aircraft; or
- (c) while in a condition unfit for the flight, whether or not the flight would otherwise be in contravention of any provision of this Order, or of any regulations made thereunder;

the Governor or that authorised person may direct the operator or the pilot-in-command of the aircraft that he is not to permit the aircraft to make the particular flight or any other flight of such description as may be specified in the direction, until the direction has been revoked by the Governor or by an authorised person, and the Governor or that authorised person may take such steps as are necessary to detain the aircraft.

(2) For the purposes of paragraph (1) the Governor or any authorised person may enter upon and inspect any aircraft.