



Factories Act 1937

1937 CHAPTER 67 1 Edw 8 and 1 Geo 6

PART II

SAFETY (GENERAL PROVISIONS).

12 Prime movers.

- (1) Every flywheel directly connected to any prime mover and every moving part of any prime mover, except such prime movers as are mentioned in subsection (3) of this section, shall be securely fenced, whether the flywheel or prime mover is situated in an engine-house or not.
- (2) The head and tail race of every water wheel and of every water turbine shall be securely fenced.
- (3) Every part of electric generators, motors and rotary converters, and every flywheel directly connected thereto, shall be securely fenced unless it is in such a position or of such construction as to be as safe to every person employed or working on the premises as it would be if securely fenced.