

SCHEDULE 4

LIFERAFTS

PART VIII

GAS INFLATION SYSTEM

General

1.7 The inflation system shall not be damaged in stowage and shall operate in a satisfactory manner throughout the air temperature range -30°C to $+65^{\circ}\text{C}$.