SCHEDULE Article 2

## CLASSES OF FIREPLACE WHICH ARE EXEMPT

## Class of fireplace **Conditions** The Dunsley Yorkshire 1. The fireplace must be installed, maintained and operated Woodburning Stove in accordance with the manufacturer's instructions dated 4 manufactured by Dunsley Heat December 2004 and bearing the reference D13W. Limited 2. No fuel may be used other than dry untreated wood. The Home and Hearth 1. The fireplace must be installed, maintained and operated in Technologies Quadra-Fire accordance with the manufacturer's instructions dated 9 October 2100 Millennium Freestanding 2003 and bearing the reference 250-6931B. Wood Burning Stove 2. No fuel may be used other than dry-cured untreated wood manufactured by Hearth & of maximum size $38.1 \times 10.16 \times 5.08$ cm. Home Technologies, 1445 North Highway, Colville, WA

The Home and Hearth Technologies Quadra-Fire Yosemite Freestanding Wood Burning Stove manufactured by Home and Hearth Technologies, 1445 North Highway, Colville, WA 99114, USA.

99114, USA.

The Home and Hearth Technologies Quadra-Fire Cumberland Gap Freestanding Wood Burning Stove manufactured by Home and Hearth Technologies, 1445 North Highway, Colville, WA 99114, USA.

The Orchard Ovens models: FVR Speciale 80, 100, 110, 110 × 160 and 120; TOP Superiore 100 and 120; GR 100, 120, 140, 120 × 160, 140 × 160, 140 × 180 and 180; OT 100, 120, 140, 120 × 160, 140 × 160, 140 × 180 and 180; and the Valoriani Piccolo; manufactured by Valoriani of Via Caselli alla Fornace, 213, 50066 Reggello, Firenze, Italy.

- **1.** The fireplace must be installed, maintained and operated in accordance with the manufacturer's instructions dated 4 June 2003 and bearing the reference 7004-187.
- **2.** No fuel may be used other than dry-cured untreated wood of maximum size  $38.1 \times 10.16 \times 5.08$ cm.
- 1. The fireplace must be installed, maintained and operated in accordance with the manufacturer's instructions dated 8 July 2003 and bearing the reference 7006-186.
- **2.** No fuel may be used other than dry-cured untreated wood of maximum size  $43.18 \times 10.16 \times 10.16$ cm.
- 1. The fireplace must be installed, maintained and operated in accordance with the manufacturers' instructions dated 25 October 2004 and bearing the references:

Instruction: Model
OOLInst.1: FVR 80
OOLInst.2: FVR 100

1

Class of fireplace	Conditions	
	OO LInst.3:	FVR 110
	OOLInst.4:	FVR 120
	OOLInst.5:	FVR 110 × 160
	OOLInst.6:	TOP 100
	OOLInst.7:	TOP 120
	OOLInst.8:	GR 100 and OT 100
	OOLInst.9:	GR 120 and OT 120
	OOLInst.10:	GR 140 and OT 140
	OOLInst.11:	GR 120 $\times$ 160 and OT 120 $\times$ 160
	OOLInst.12:	GR 140 $\times$ 160 and OT 140 $\times$ 160
	OOLInst.13:	GR 140 $\times$ 180 and OT 140 $\times$ 180
	OOLInst.14:	GR 180 and OT 180
	OOLInst.15:	Valoriani Piccolo
	2. No fuel may be used other than untreated dry wood.	
The Wood Waste Technology Heater, models WT10 and WT15, manufactured by Wood Waste Technology.	1. The fireplace must be installed, maintained and operated in accordance with the manufacturer's instructions dated January 2005 and bearing the reference WT/a/19/1/05 with regard to model WT10 or WT15/a/19/01/05 with regard to model WT15.	
	<b>2.</b> No fuel may be used other than offcuts of untreated hardwood or softwood.	