Status: EU Directives are being published on this site to aid cross referencing from UK legislation. After IP completion day (31 December 2020 11pm) no further amendments will be applied to this version.

ANNEX VI

DEFINITIONS

A thermal energy meter is an instrument designed to measure the thermal energy which, in a thermal energy exchange circuit, is given up by a liquid called the thermal energy-conveying liquid.

A thermal energy meter is either a complete instrument or a combined instrument consisting of the sub-assemblies, flow sensor, temperature sensor pair, and calculator, as defined in Article 4(2), or a combination thereof

θ	=	the temperature of the thermal energy-conveying liquid;
θ_{in}	=	the value of θ at the inlet of the thermal energy exchange circuit;
θ _{out}	=	the value of θ at the outlet of the thermal energy exchange circuit;
$\Delta \theta$	=	the temperature difference $\theta_{in} - \theta_{out}$ with $\Delta_{\theta} \ge 0$;
θ_{max}	=	the upper limit of θ for the thermal energy meter to function correctly within the MPEs;
θ_{min}	=	the lower limit of θ for the thermal energy meter to function correctly within the MPEs;
$\Delta \theta_{max}$	=	the upper limit of $\Delta \theta$ for the thermal energy meter to function correctly within the MPEs;
$\Delta \theta_{min}$	=	the lower limit of $\Delta \theta$ for the thermal energy meter to function correctly within the MPEs;
q	=	the flow rate of the thermal energy conveying liquid;
q _s	=	the highest value of q that is permitted for short periods of time for the thermal energy meter to function correctly;
q _p	=	the highest value of q that is permitted permanently for

Document Generated: 2023-11-13 Status: EU Directives are being published on this site to aid cross referencing from UK legislation. After IP completion day (31 December 2020 11pm) no further amendments will be applied to this version.

		the thermal energy meter to function correctly;
q _i	=	the lowest value of q that is permitted for the thermal energy meter to function correctly;
Р	=	the thermal power of the thermal energy exchange;
P _s	=	the upper limit of P that is permitted for the thermal energy meter to function correctly.