## SCOTTISH STATUTORY INSTRUMENTS

# 2010 No. 272

# **CLEAN AIR**

The Smoke Control Areas (Exempt Fireplaces) (Scotland) Order 2010

Made	30th June 2010
Laid before the Scottish	
Parliament	1st July 2010
Coming into force	27th September 2010

The Scottish Ministers make the following Order in exercise of the powers conferred by section 21 of the Clean Air Act 1993(1) and all other powers enabling them to do so.

In accordance with that section, they are satisfied that the classes of fireplace exempted by this Order can be used for burning fuel other than authorised fuels(2) without producing any smoke or a substantial quantity of smoke.

#### Citation, commencement and extent

**1.**—(1) This Order may be cited as the Smoke Control Areas (Exempt Fireplaces) (Scotland) Order 2010 and comes into force on 27th September 2010.

(2) This Order extends to Scotland only.

#### Fireplaces exempted from section 20 of the Clean Air Act 1993

**2.** The fireplaces described in the Schedule that comply with the conditions specified in relation to each of them are exempt from the provisions of section 20 (prohibition on emission of smoke in smoke control area) of the Clean Air Act 1993.

### Revocation

**3.** The Smoke Control Areas (Exempt Fireplaces) (Scotland) Order 2009(**3**) is revoked.

 <sup>1993</sup> c.11. The functions of the Secretary of State under section 21 were transferred to the Scottish Ministers by virtue of section 53 of the Scotland Act 1998 (c.46).

<sup>(2)</sup> Fuels declared by the Scottish Ministers to be authorised fuels for the purposes of Part III of the Clean Air Act 1993 under section 20(6) of that Act are specified in S.S.I. 2010/271.

<sup>(3)</sup> S.S.I. 2009/214.

St Andrew's House, Edinburgh 30th June 2010

*R CUNNINGHAM* Authorised to sign by the Scottish Ministers

### SCHEDULE

Article 2

## Exempted fireplaces

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
1.	Any fireplace specially designed or adapted for combustion of liquid fuel and equipped with mechanical stokers.		The fuel for which the mechanical stoker was designed.
2.	Any fireplace (other than a fireplace fired by pulverised fuel) constructed on or after 31st December 1956 and installed before 28th April 1982 and equipped with mechanical stokers, or adapted between those dates for use with such stokers.		The fuel for which the mechanical stoker was designed.
3.	Any fireplace designed to burn coal (other than a fireplace fired by pulverised coal) with a heating capacity exceeding 150,000 British thermal units per hour constructed and installed on or after 31st December 1956 and equipped with mechanical stokers or adapted on or after that date for use with such stokers.		The fuel for which the mechanical stoker was designed.
4.	The APE Saffire Boiler (in the sizes, expressed in British Thermal Units (BTUs) per hour, as 1M to 8M, 10M and 12M) manufactured by Air	The manufacturer's instructions dated 27th August 1982 and bearing the reference "SAF 250-3000/ HW & /S.".	Sawdust, or shavings, or mixtures of sawdust, shavings and off-cuts, being fuel containing (by weight) not more than

Fireplace			itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Pollution Engineering Limited.		1 per cent of plastic material.
5.	The Apollo incinerator types 10, 25 and 50 manufactured by Apollo Incineration Systems Limited.	The manufacturer's instructions dated 2nd November 1992 and bearing the reference "Apollo 10-25-50".	Wood, wood shavings, cardboard and polythene.
6.	Arimax Bio 300 kW, Arimax Bio 400 kW and Arimax Bio 500 kW, manufactured by Artierm Oy, PO Box 59, Fin — 43101, Saarijarvi, Finland.	Instruction manual reference "INSTALLATION AND OPERATION MANUAL Arimax Bio 120-3000 kW" dated 30/03/2010.	6-8mm wood pellets with a moisture content of less than 10 per cent.
7.	The Babcock Worsley Fluidised Bed Combuster manufactured by Babcock Robey Limited.	The manufacturer's instructions dated 30th April 1986 and which bear the reference "No. C06/0016".	The waste derived fuel recommended in the manufacturer's instructions.
		The fireplace must be operated as a single unit with— (a) the Tollemache Drier manufactured by Newell Dunford Limited; and (b) The Venturi Scrubber manufactured by Air Pollution Control Limited.	
8.	The B9 Energy Wood Chip Gasifier Unit manufactured by B9 Energy Biomass Limited, Unit 22, Northland Road Industrial Estate,	The manufacturer's instructions dated 2002 and bearing the reference "001/ B9ENERGYBIOMASS	Untreated wood chips; shredded wood; or small untreated pieces of wood. ".

Fireplace		Conditions	
	Londondarry, Northorn	The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Londonderry, Northern Ireland.		
9.	The Beech Wood Fired Pizza Oven manufactured by Beech Wood Fired Ovens, Brisbane, Australia.	The manufacturer's instructions dated 3rd March 2000 and bearing the reference "BBP236UK".	Untreated dry hardwood.
10.	The Binder Wood Fired Boiler models RRK 22-49 (49 kW output) manufactured by Binder Gesellschaft mit beschränkter Haftung (GmbH) of Austria.	The manufacturer's and Wood Energy Limited's instructions 'Binder Equipment Installation, Commissioning and Maintenance' dated 17th May 2005, reference WELBinderManualrevO revision 0.	Wood pellets or wood chips.
11.	The Binder Wood Fired Boiler models RRK 80-175 (75– 149 kW output) with cyclone models ZA 80–175 manufactured by Binder Gesellschaft mit beschränkter Haftung (GmbH) of Austria.	The manufacturer's and Wood Energy Limited's instructions 'Binder Equipment Installation, Commissioning and Maintenance' dated 17th May 2005, reference WELBinderManualrevO revision 0.	Wood pellets or wood chips.
12.	The Binder Wood Fired Boiler models RRK 130-250 (185-230 kW output), RRK 200-350 (250-300 kW output), RRK 400-600 (350-500 kW output) and RRK 640-850 (650-840 kW output) with cyclone model type ZA manufactured by Binder Gesellschaft	The manufacturer's and Wood Energy Limited's instructions 'Binder Equipment Installation, Commissioning and Maintenance' dated 17th May 2005, reference WELBinderManualrev0 revision 0.	Wood pellets or wood chips. 9.doc,

Fireplace		Conditions	
	mit beschränkter	The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Haftung (GmbH) of Austria.		
13.	The Binder Wood Fired Boiler model RRK 1000 (1200 kW output) with multi- cyclone model MZA manufactured by Binder Gesellschaft mit beschränkter Haftung (GmbH) of Austria.	The manufacturer's and Wood Energy Limited's instructions 'Binder Equipment Installation, Commissioning and Maintenance' dated 17th May 2005, reference WELBinderManualrevO revision 0.	Wood pellets or wood chips.
14.	The Binder Wood Fired Boiler model RRK 1200-1650 with Binder model MZA multi-cyclone and automatic ignition manufactured by Binder Gesellschaft mit beschränkter Haftung (GmbH) of Austria.	Wood Energy Limited's operating instructions for Binder appliances referenced: 2009 July Binder O&M revision8.doc. Operation and Maintenance Manual, Revision 8, dated 15th July 2009.	Wood pellets or wood chips.
15.	The Binder Wood Fired Boiler model RRK 1800-2300 with Binder model MZA multi-cyclone and automatic ignition manufactured by Binder Gesellschaft mit beschränkter Haftung (GmbH) of Austria.	Wood Energy Limited's operating instructions for Binder appliances referenced: 2009 July Binder O&M revision8.doc. Operation and Maintenance Manual, Revision 8, dated 15th July 2009.	Wood pellets or wood chips.
16.	The Binder Wood Fired Boiler model RRK 2500-3000 with Binder model MZA multi-cyclone and automatic ignition manufactured by	Wood Energy Limited's operating instructions for Binder appliances referenced: 2009 July Binder O&M revision8.doc.	Wood pellets or wood chips.

Fireplace		Conditions	
	Binder Gesellschaft mit beschränkter Haftung (GmbH) of Austria.	The fireplace must be installed, maintained and operated in accordance with the following specifications Operation and Maintenance Manual, Revision 8, dated 15th July 2009.	Fuels that must be used (other than authorised fuels)
17.	Biomatic 220 and 250 fitted with Zyklovent 220-250 cyclone separator manufactured by HERZ Armaturen GmbH, Geschäftsbereich HERZ, Feuerungstechnik, A-8272 Sebersdorf 138, Austria.	The manufacturer's instructions dated April 2005, reference Bedienungsanleitung Englisch v2.0 doc.	Chipped wood, wood pellets or planed wood shavings.
18.	Biomatic 300, 350, 400 and 500 fitted with Zyklovent 300-500 cyclone separator manufactured by HERZ Armaturen GmbH, Geschäftsbereich HERZ, Feuerungstechnik, A-8272 Sebersdorf 138, Austria.	The manufacturer's instructions dated April 2005, reference Bedienungsanleitung Englisch v2.0 doc.	Chipped wood, wood pellets or planed wood shavings.
19.	Broag-Gilles HPK- RA 13 kW, 15 kW, 20 kW, 25 kW, 30 kW, 35 kW, 40 kW, 45 kW, 49 kW, 60 kW, 70 kW, 75 kW, 85 kW, 95 kW, 100 kW, 120 kW and 145 kW, all manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	The manufacturer's operating instructions dated January 2007, reference Broag- Gilles/0-145/1.	Wood pellets or wood chips.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
20.	Broag-Gilles HPK USK 150 kW, 180 kW, 240 kW and 300 kW, manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	The manufacturer's operating instructions dated January 2007, reference Broag- Gilles/150-300/1.	Wood pellets or wood chips.
21.	Carron Stove manufactured by Jig UK Limited, Hurlingham Business Park, Fulbeck Heath, Grantham, Lincolnshire, NG32 3HL.	Instruction manual reference "91-62351" dated July 2009.	Dry and split wood logs of a maximum length of 23 cm.
22.	The CBR Flexifuel Heater, models 150 and 200 manufactured by CBR Fabrications Limited.	The manufacturer's instructions, which bear the reference "FF/ CBR FLEXIFUEL 150/200 1989". The fireplace must not be used to burn sawdust in bulk.	Hardwood or softwood offcuts, chipboard or plastic coated chipboard.
23.	The CBR Flexifuel Heater, models 300, 400 and 600 manufactured by CBR Fabrications Limited.	The manufacturer's instructions, which bear the reference "FF/ CBR FLEXIFUEL 1987". The fireplace must not be used to burn sawdust in bulk.	Hardwood or softwood offcuts, chipboard or plastic coated chipboard.
24.	The CBR Turbo Heat, models 200, 300, 400, 500, 600 and 800 manufactured by CBR Fabrications Limited.	The manufacturer's instructions, which bear the reference "CBR Turbo Heat 88". The fireplace must not be used to burn sawdust in bulk.	Hardwood or softwood offcuts, chipboard or plastic coated chipboard.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
25.	The Charnwood Cove 1SR stove manufactured by A.J. Wells and Sons Limited, Bishops Way, Newport, Isle of Wight, PO30 5WS.	Installation and Use Instruction manual reference "COVE1SR01.10 Issue A". The air control must be adjusted so that it is 15 mm or more from the fully open position.	Wood logs.
26.	The Charnwood Tor stove manufactured by A.J. Wells and Sons Limited, Bishops Way, Newport, Isle of Wight, PO 30 5WS.	Installation and Use instruction manual reference "Tor 02.10 Issue A".	Wood logs.
27.	The Classic models 25, 35, 40, 49 and 60 wood pellet boilers manufactured by Hargassner Gesellschaft mit beschrankter Haftung (GmbH), Gunderding 8, A-4952, Weng, Austria.	The manufacturer's installation manual for the Classic Pellet Boilers reference No. 22, Pellet Boilers, Type Classic 25, 31, 35, 40, 49, 60, reference BA Classic 25L-60L Nr 21 0508.	Wood pellets.
28.	The Clearview models 650 and 750, and the Vision 500 model, manufactured by Clearview Stoves of More Works, Bishops Castle, Shropshire, SY9 5HH.	The manufacturer's instructions dated 1st January 1993 and, in the case of the Clearview models 650 and 750, bearing the reference "1/42" and, in the case of the Vision 500 model, bearing the reference "V1/42".	Firewood which has been split, stacked and air dried.
29.	The Clearview Pioneer 400, Solution 400 and Pioneer Oven wood burning stoves fitted	The manufacturer's instructions 'Operating Instructions Clearview Vision/Vision Inset/	Air-dried wood logs.

Fireplace		Conditions	
	with a tamperproof mechanical stop on the air slide/damper manufactured by Clearview Stoves of	The fireplace must be installed, maintained and operated in accordance with the following specifications Pioneer & Solution' dated 1st July 2006, reference V1/42, stamped and signed "Smoke Control".	Fuels that must be used (other than authorised fuels)
	More Works, Bishops Castle, Shropshire, SY9 5HH.		
30.	The Contura 510, Contura 520T, Contura 550, Contura 550A, Contura 550W, Contura 560T, Contura 560K, Contura 570, Contura 580, Contura 585, Contura 590, and Contura 590T, manufactured by NIBE AB, Box 134, 285 23, Markaryd, Sweden.	Installation Instruction IAV SE/EX 0726-6 611821. Lighting Instruction BAV SE/EX 0717-2 611820 A permanent stop must be in place on the air inlet to prevent closure beyond the minimum air open position.	Untreated dry wood with less than 20 per cent moisture.
31.	Contura 580W manufactured by NIBE AB, Box 134, 285 23, Markaryd, Sweden.	Installation Instruction IAV SE/EX 0740-1 511911. A permanent stop must be in place on the air inlet to prevent closure beyond the minimum air open position.	Untreated dry wood with less than 20 per cent moisture.
32.	The Corsair 300HW, 500HW and 750HW boilers manufactured by Erithglen Limited.	The manufacturer's instructions: reference "001 August 1985".	
33.	The Cove 2 SR manufactured by A.J.Wells & Sons Limited, Bishops Way, Newport, Isle of Wight, PO30 5WS.	Instruction manual reference "Cove2SR 07.09 IssB" dated July 2009. A permanent stop must be in place on	Dry and split wood logs of a maximum length of 23 cm.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications air control to prevent closure beyond 14mm from the fully closed position.	Fuels that must be used (other than authorised fuels)
34.	The Cronspisen stove, using the five channel chimney system, manufactured by Cronspisen Produktion AB.	The manufacturer's instructions bearing the reference "January 1992. Serial No: UM 351B".	Firewood that has been split, stacked and air-dried.
35.	CTC Ecoflex 15 and 20 manufactured by Enertech AB, Box 313, S-341 26 Ljungby, Sweden.	Instruction Manual referenced "161 505 27 06/1" and dated 20/02/2007.	Wood pellets.
36.	The Defiant Encore manufactured by VCW International Limited.	The manufacturer's instructions dated November 1991 bearing the reference "200-8632".	Firewood that has been split, stacked and air-dried.
37.	Dimplex SE Selborne 5 manufactured by ESSE Engineering	Instruction manual reference "SE Selborne 5 Issue 1" dated 08 2009.	Wood logs.
	Limited, Ouzledale Foundry, Long Ing, Barnoldswick, Lancashire, BB18 6BN.	All appliances must be fitted with a mechanical stop to prevent closure beyond the 50 per cent open position.	Wood logs.
38.	Dovre 250 (model number DV-250) manufactured by Dovre NV, Nijverheidsstraat 18, BE-2381 Weelde, Belgium.	Instruction manual reference "PM 250 Issue 1". A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 75 per cent open position.	Untreated dry wood.
39.	The Dovre woodstove models 500CBW	The manufacturer's instructions dated	Wood.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	and 700CBW manufactured by Dovre Castings Limited, including those models referred to by their former reference numbers, 500G and 700G respectively.	October 1995 bearing the following references:— (a) for model 500G: "500G"; and (b) for model 700G: "700G".	
40.	The Dunsley Yorkshire Stove manufactured by Dunsley Heat Limited.	The manufacturer's instructions dated 5th August 1998, reference A/22160 as amended by those dated 4th December 2004, reference D13.	Untreated dry wood. Peat or peat briquettes with, in either case, less than 25 per cent moisture. Union Coal Briquettes, manufactured by Rheinbraun AG of Germany, comprising lignite compressed into briquettes of approximately 15 cm in length with square ends and with a sulphur content not exceeding 1 per cent of the total weight ("UCB"). CPL Wildfire, manufactured by Coal Products Limited, Immingham, which— (a) comprise bituminous coal with a volatile content of 32– 36 per cent (as to approximately 96 per cent of the total weight) and a cold cure resin binder (as to the remaining weight);

Fireplace	Conditions		
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
41			<ul> <li>(b) are manufactured from those constituents by a process involving roll– pressing;</li> <li>(c) have an average weight of either 80– 90 grammes or 160-170 gramme and</li> <li>(d) have a sulphur content not exceeding 1.8 per cent of the total weight ("CPL").</li> </ul>
41.	The Dunsley Yorkshire Multifuel Stove manufactured by Dunsley Heat Limited.	The manufacturer's instructions dated 5th August 1998, reference A/22160 as amended by those dated 4th December 2004, reference D13.	Untreated dry wood. Peat or peat briquettes with, in either case, less than 25 per cent moisture. UCB or CPL.
42.	The Dunsley Yorkshire Multifuel Stove and Boiler manufactured by Dunsley Heat Limited.	The manufacturer's instructions dated 4th October 2004, reference GHD/ DUN4B/1.	Untreated dry wood. Peat or peat briquettes with, in either case, less than 25 per cent moisture. UCB or CPL.
43.	The Dunsley Yorkshire Woodburning Stove manufactured by Dunsley Heat Limited.	The manufacturer's instructions dated 4th December 2004, reference D13W.	Untreated dry wood.
44.	The Dunsley Yorkshire Woodburning Stove and Boiler manufactured by Dunsley Heat Limited.	The manufacturer's instructions dated 4th December 2004, reference D13W together with the	Untreated dry wood.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications manufacturer's	Fuels that must be used (other than authorised fuels)
		instructions dated 4th October 2004 reference GHD/ DUN4B/1.	
45.	Earlswood manufactured by ACR Heat Products Limited, Unit One, Weston Works, Weston Lane, Tyseley, Birmingham, B11 3RP.	Instruction manual reference "EMIMF technical manual" dated 02 2009. When the primary out control is in the closed position, it must remain open by 5mm and be prevented	Wood logs.
		from closing fully by a screw.	
46.	Eccostove manufactured by Landy Vent, Foster House, 2 Redditch Road, Studley, Warwickshire, B80 7AX.	Instruction manual reference "02/10" dated 10/02/2010. A system that prevents closure of the secondary air flaps to less than 4mm (3 Turns) open position must be fitted.	Wood logs.
47.	The Eclipse Junior, Standard, Senior, Jumbo 30 and Jumbo 50 incinerators manufactured by Northern Incinerators Limited.	The manufacturer's instructions dated 21st June 1988 and which bear the reference "NORCIN/ TECH/88".	Fuel consisting of paper, cardboard cartons, scrap wood, foliage, combustible floor sweepings and other waste from domestic, commercial and industrial activities containing no more than 20 per cent of restaurant and cafeteria waste, and containing less than 5 per cent by weight of coated papers, plastic or rubber waste.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
48.	The Extraflame Babyfiamma, Bella and Bella Lux, Clementina, Comfort Maxi, Contessa, Divina, Divina Plus and Divina Steel, Duchessa and Duchessa Steel, Ecologica, Esmeralda and Esmeralda Crystal, Falò 1CP, Falò 2CP and Falò 1XP, Isabella, Karolina, Preziosa, all of which are manufactured by Extraflame S.p.a. in Montecchio Precalcino (Vicenza), Italy.	The manufacturer's operating instructions dated 5th March 2007, reference 004275101 011.	Wood pellets.
49.	The Extraflame Comfort Mini manufactured by Extraflame S.p.a. in Montecchio Precalcino (Vicenza), Italy.	The manufacturer's operating instructions dated 2nd October 2006, reference 004275115 REV 005.	Wood pellets.
50.	The Extraflame Idro manufactured by Extraflame S.p.a. in Montecchio Precalcino (Vicenza), Italy.	The manufacturer's operating instructions dated 28th August 2006, reference 004275128 REV 002.	Wood pellets.
51.	The Extraflame Lucrezia Idro and Lucrezia Steel manufactured by Extraflame S.p.a. in Montecchio Precalcino (Vicenza), Italy.	The manufacturer's operating instructions dated 12th July 2006, reference 004275110 REV 011.	Wood pellets.
52.	The Farm 2000 boiler models BB154, BB154A and BB154/2 (when used with the Farm 2000 conversion	The manufacturer's instructions which— (a) in the case of the installation instructions	Cereal straw.

Fireplace		Cona	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	kit BB154/2Vcx) manufactured by Farm 2000 Limited.	<ul> <li>are dated May 1994 and bear the reference "BB154/2VC"; and</li> <li>(b) in the case of the maintenance and operation instructions are dated September 1993 and bear the reference "BB154/2V".</li> </ul>	
53.	The Farm 2000 model HT6 (when used with the Farm 2000 conversion kit HT60cx), the HT6Plus and HT600 (when each is used with the Farm 2000 conversion kit HT70cx) and the HT7 and HT8 (when each is used with the Farm 2000 conversion kit HT80cx), manufactured by Farm 2000 Limited.	The manufacturer's instructions which— (a) in the case of the installation instructions are dated May 1994 and bear the references "HT6780" and "HT6781"; and (b) in the case of the maintenance and operation instructions are dated 1st July 1993 and bear the reference "HT60/70/80".	Cereal straw.
54.	The Farm 2000 boilers HT60, HT70, HT80 and BB154/2V manufactured by Farm 2000 Limited.	The manufacturer's instructions which, in the case of models HT60, HT70 and HT80, are dated 1st July 1993 and bear the reference "HT60/70/80", and, in the case of model BB154/2V, are dated 1st September 1993 and bear the reference "9/93".	Cereal straw.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
55.	Firefox 5CB, Vega 100CB and Sirius 405CB (4.9kW) stoves manufactured by Percy Doughty & Co, Imperial Point, Express Trading Estate, Stonehill Road, Farnworth, Bolton, BL4 9TN.	Instruction manual reference "FFXCB-A" dated January 2010.	Wood logs.
56.	Fireline manufactured by Broseley Fires Limited, Knights Way, Battlefield Enterprise Park, Shrewsbury, Shropshire, SY1 3AB.	Instruction manual reference "09TJD" dated 01 2010. A system that prevents the closure of the secondary air flaps to less than 8mm open position must be fitted.	Wood logs.
57.	Fireline manufactured by Charlton and Jenrick Limited, Charlton and Jenrick, G1-G2, Halesfield 5, Telford, Shropshire, TF7 4OJ.	Instruction manual reference "Issue 03" dated 03/10. A system that prevents the closure of the secondary air control beyond the 3.5mm open position must be fitted.	Wood logs.
58.	Fireline FP5, Fireline FX5, Fireline FPi 5kW, and Fireline FXi 5kW manufactured by Charlton and Jenrick Limited, Charlton and Jenrick, G1-G2, Halesfield 5, Telford, Shropshire, TF7 4OJ.	Instruction manual reference "Issue 03" dated 03/10. A system that prevents the closure of the secondary air control beyond the 3.5mm open position must be fitted.	Wood logs.
59.	Firematic 25, 50, 90 and 150 manufactured by HERZ Armaturen GmbH,	The manufacturer's instructions dated June 2005, reference Bedienungsanleitung	Chipped wood, wood pellets or planed wood shavings.

Fireplace		Cona	litions
	Geschaftsbereich	The fireplace must be installed, maintained and operated in accordance with the following specifications Firematic V 1.1 ENG doc.	Fuels that must be used (other than authorised fuels)
	HERZ, Feuerungstechnik, A-8272 Sebersdorf 138, Austria.		
60.	Firematic 45 and 60 manufactured by HERZ Armaturen GmbH, Geschaftsbereich HERZ, Feuerungstechnik, A-8272 Sebersdorf 138, Austria.	Instruction manual reference "05.007 operating instructions – FM (1Ph) 20 35 45 60 v 2.3" dated 08/2009.	Wood pellets conforming to ÖNORM M 7135(4) with a diameter of 6mm or wood chips up to a maximum size of 50mm and maximum water content of 35%.
61.	Franco Belge Model 134 08 11 Savoy EA 8kW output wood burning stove manufactured by Franco Belge, Staub Fonderie SARL, Rue Orphée Variscotte, 59660, Merville, France.	The Savoy EA Technical Manual, document reference 1290-1, reviewed 9th July 2009.	Wood logs.
62.	Fröling P4, 8, 15, 20, 25, 32, 38, 48 and 60 Pellet Boilers manufactured by Fröling Heizkessel- und Behälterbau GmbH, Industriestraβe 12, A-4710 Grieskirchen, Austria.	Instruction manual reference "B0430408_en" dated July 2009.	Wood pellets with a diameter of 6mm.
63.	Fröling Turbomat 150 and 220 manufactured by Fröling Heizkessel- und Behälterbau GmbH, Industriestraβe 12, A-4710 Grieskirchen, Austria.	The manufacturer's operating instructions dated November 2004, reference B0340004.	Wood pellets or wood chips.

<sup>(4)</sup> This standard is issued by the Austrian Standards Institute. Copies may be obtained from that Institute at Heinestrasse, 38, 1020 Vienna, Austria, http://www.austrian-standards.at.

Fireplace	Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)	
64.	Fröling Turbomat 320 and 500 manufactured by Fröling Heizkessel- und Behälterbau GmbH, Industriestraβe 12, A-4710 Grieskirchen, Austria.	The manufacturer's operating instructions dated November 2004, reference B0340004.	Wood pellets or wood chips.	
65.	The Fulgora Slow Combustion Stove manufactured by Fulgora Stoves Limited.		Wood waste in clean condition.	
66.	Gilles HPK-RA 13 kW, 15 kW, 20 kW, 25 kW, 30 kW, 35 kW, 40 kW, 45 kW, 49 kW, 60 kW, 70 kW, 75 kW, 85 kW, 95 kW, 100 kW, 120 kW and 145 kW manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	Operating instructions reference Gilles/0-145/1 and dated January 2007.	Wood pellets or wood chips.	
67.	Gilles HPK USK 150 kW, 180 kW, 240 kW and 300 kW manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	Operating instructions reference Gilles/150-300/1 and dated January 2007.	Wood pellets or wood chips.	
68.	Gilles HPK USK 360 kW manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	Operating instructions reference Gilles 360/1 and dated January	Wood pellets or wood chips.	
69.	Gilles UTSK 450 kW and 550 kW boilers	Operating instructions reference Gilles/360/1	Wood pellets or wood chips.	

Fireplace			litions
	manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810	The fireplace must be installed, maintained and operated in accordance with the following specifications and dated January 2008.	Fuels that must be used (other than authorised fuels)
70.	Gmunden, Austria. Gilles UTSK 700 kW and 900 kW boilers manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	Operating instructions reference Gilles/360/1 and dated January 2008.	Wood pellets or wood chips.
71.	Gilles UTSK 1200 kW and 1600 kW boilers manufactured by GILLES Energie- und Umwelttechnik GmbH, Koaserbauer Str. 16 A-4810 Gmunden, Austria.	Operating instructions reference Gilles/360/1 and dated January 2008.	Wood pellets or wood chips.
72.	Guntamatic Biocom and Powercorn 50 and 75 manufactured by GUNTAMATIC Heiztechnik GmbH, A-4722 PEUERBACH Bruck 7, Austria.	Instruction manual reference "GUN/BIO/ OP/V1/0709" dated 29/07/09.	Wood pellets with a diameter of 6mm and a length of between 10mm and 30mm.
73.	Guntamatic Powerchip 50 and 75 manufactured by GUNTAMATIC Heiztechnik GmbH, A-4722 PEUERBACH Bruck 7, Austria.	Instruction manual reference "GUN/ POW/OP/V1/0709" dated 29/07/09.	Wood pellets with a diameter of 6mm and a length of between 10mm and 30mm.
74.	Guntamatic Biocom and Powercorn 100 manufactured by GUNTAMATIC Heiztechnik GmbH, A-4722 PEUERBACH Bruck 7, Austria.	Instruction manual reference "GUN/BIO/ OP/V1/0709" dated 29/07/09.	Wood pellets with a diameter of 6mm and a length of between 10 and 30mm or wood chip with less than 30 per cent moisture content and meeting

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
			ÖNORM M 7133: 1998( <b>5</b> ) size class G30.
75.	Guntamatic Powerchip 100 manufactured by GUNTAMATIC Heiztechnik GmbH, A-4722 PEUERBACH Bruck 7, Austria.	Instruction manual reference "GUN/ POW/OP/V1/0709" dated 29/07/09.	Wood pellets with a diameter of 6mm and a length of between 10 and 30mm or wood chip with less than 30 per cent moisture content and meeting ÖNORM M 7133: 1998 size class G30.
76.	The HSV 50 + WTH 45, 49 or 55 boilers manufactured by Hargassner Gesellschaft mit beschrankter Haftung (GmbH), Gunderding 8, A-4952, Weng, Austria.	The manufacturer's installation manual version 44 for Wood Chip and Pellet Stoves, Type HSV 30-100 (reference BA HSV30-100 RA/ RAP V44 0608).	Wood chip or wood pellets.
77.	The HSV 80 + WTH 70 or 80 boilers manufactured by Hargassner Gesellschaft mit beschrankter Haftung (GmbH), Gunderding 8, A-4952, Weng, Austria.	The manufacturer's installation manual version 44 for Wood Chip and Pellet Stoves, Type HSV 30-100 (reference BA HSV30-100 RA/RAP V44 0608).	Wood chip or wood pellets.
78.	The HSV 100 + WTH 100 boiler manufactured by Hargassner Gesellschaft mit beschrankter Haftung (GmbH), Gunderding 8,	The manufacturer's installation manual version 44 for Wood Chip and Pellet Stoves, Type HSV 30-100 (reference BA HSV30-100 RA/ RAP V44 0608).	Wood chip or wood pellets.

<sup>(5)</sup> This standard is issued by the Austrian Standards Institute. Copies may be obtained from that Institute at Heinestrasse, 38, 1020 Vienna, Austria, http://www.austrian-standards.at.

Fireplace			itions
	A-4952, Weng,	The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
79.	Austria. The Haat LD, MD and HD incinerators manufactured by Haat Incineration Limited.	The manufacturer's instructions dated March 1988 and which bear the reference "HAAT/I/CAA/3/88".	Paper, cardboard cartons, scrap wood, foliage, combustible floor sweepings and other waste from domestic, commercial and industrial activities containing no more than 20 per cent of restaurant and cafeteria waste, and containing less than 5 per cent by weight of coated papers, plastic or rubber waste.
80.	The Haat Pioneer ABI Incinerators, models 12, 20, 28 and 36 manufactured by Haat Incineration Limited.	The manufacturer's instructions bearing the reference "HAAT/2/ CAA/10/89".	The following fuels used in the mixtures by volume recommended in Appendix A of the manufacturer's instructions:— paper, cardboard, corrugated paper, office or domestic waste, wood, polythene sheet or foam, polypropylene, nylon, polyethylene, rubber foam backed carpet, polystyrene, polyurethane and glass fibre reinforced plastics.
81.	Hamont CATfire 350 USZI pellet boiler fitted with CATfire 300 cyclone, both manufactured by Hamont Contracting and Trading spol. s.r.o., Sedlište 227, postal code	Operating instruction reference "Operating Manual for Boilers CATfire 150-500 kW" effective from 1/1/2008.	Wood pellets of diameter 6 mm and a maximum length of 30 mm.

Fireplace		Cond	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	739 36, district Frýdek – Mistek Czech Republic.		
82.	Handöl 31, Handöl 31A, Handöl 32, Handöl 32A, Handöl 33T, Handöl 34T, Handöl 35T, Varde Ovne Look 1, Varde Ovne Look 2, and Varde Ovne Look 3, manufactured by NIBE AB, Box 134, 285 23, Markaryd, Sweden.	Installation Instructions IAV SE- EX 0811-4 511941. Lighting Instructions BAV SE-EX H30 511942. A permanent stop must be in place on the air inlet to prevent closure beyond the minimum air open position.	Untreated dry wood with less than 20 per cent moisture.
83.	Handöl 50, Handöl 51, Handöl 52, Handöl 52T, Handöl 53, Handöl 54, Handöl 54T, Handöl 51L, Varde Ovne S1, Varde Ovne S2 and Varde Ovne S3, manufactured by NIBE AB Box 134, 285 23, Markaryd, Sweden.	Installation Instructions IAV SE- EX 0737-4 511866. Lighting Instructions BAV SE-EX 0717-1 511865. A permanent stop must be in place on the air inlet to prevent closure beyond the minimum air open position.	Untreated dry wood with less than 20 per cent moisture.
84.	Highlander 5 Clean Burn manufactured by Dunsley Heat Limited, Bridge Mills, Huddersfield, Holmfirth, West Yorkshire, HD9 3TW.	Instruction manual reference "Highlander. The Dunsley- Enviroburn-5. Clean Burn Stove Installation and operation instructions. D-12-01-09, D060-01-09,	Wood logs conforming to BS EN 13240:2001(6).

This standard is issued by the British Standards Institution, ISBN 978 0 580 60015 9. Copies may be obtained from that Institution, at 389, Chiswick High Road, London, W4 4AL, http://www.bsigroup.com. 23 (6)

Fireplace			itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications D13-01-09, D-12-12-08".	Fuels that must be used (other than authorised fuels)
85.	The Holden Heat House 29.3kw and 45.4kw underfeed bituminous coal burning boilers manufactured by Holden Heat plc.	The manufacturer's instructions which— (a) in the case of the installation instructions bear the reference "HH86 1B"; and (b) in the case of the user instructions bear the reference "HH86/1".	The washed coals recommended in the manufacturer's user instructions.
86.	The Hounsell Sawdust Burning Stove previously manufactured by John Hounsell (Engineers) Limited.		Wood waste in clean condition.
87.	The Housewarmer manufactured formerly by Ideal Standard Limited and latterly by Stelrad Group Limited.		Washed coal singles of nominal size 12.5 mm to 28 mm.
88.	The Hoval AgroLyt 20, 25, 35, 45 and 50 manufactured by Hoval AG, Austrasse 70, FL-9490 Vaduz, Liechtenstein.	The manufacturer's— (a) installation manual reference 4 205/194/00, dated 01/06, and (b) Operation manual reference 4 205 193/00 dated 06/06.	Wood logs with less than 20 per cent moisture.
89.	The Hoval BioLyt 50 wood pellet fired boiler (49 kW thermal output) manufactured by Hoval AG, Austrasse 70, FL-9490, Vaduz, Liechtenstein.	The manufacturer's— (a) technical information and installation instructions dated 10/05, reference	Wood pellets.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications 4 204 794/00,	Fuels that must be used (other than authorised fuels)
		(b) operating instructions dated 01/06 reference 4 204 793/01.	
90.	The Hoval Biolyt 50 and 70 models manufactured by Hoval AG, Austrasse 70, FL-9490 Vaduz, Liechtenstein.	Installation and operation manuals reference 4 204 794/01 and 4 204 793/02 dated 06/07.	6 mm diameter wood pellets.
91.	Hoval Forester UFS 180, 240, 300, 360, 450, 550, 700, 900, 1200 and 1600 manufactured by Schmid AG, Wood firing Systems, PO Box 42, CH-8360 Eschlikon, Switzerland.	Instruction manual reference "Forester UFS" dated November 2009.	Wood pellets or wood chips following CEN/ TS 14961:2005(7).
92.	The Hoval STU 150, 200, 250, 300, 350, 425 and 500 manufactured by Hoval UK Ltd, Northgate, Newark-on-Trent, Nottinghamshire, NG24 1JN.	Installation and operation manual referenced STUman/01 dated 11/07 or the installation and operation manual referenced STU/ man/01/1 dated 06/08.	6 mm diameter wood pellets.
93.	The Hoval STU 600, 800 and 1000 manufactured by Hoval UK Ltd, Northgate, Newark-on-Trent, Nottinghamshire, HG24 1JN.	Installation and operation manual referenced STU/ man/01/1 dated 06/08.	6 mm diameter wood pellets.

<sup>(7)</sup> This standard is issued by the European Committee for Standardisation (CEN). Copies may be obtained from CEN at Avenue Marnix 17, B-1000, Brussels, Belgium, http://www.cenorm.be. 25

Fireplace			litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
94.	The Hughes Edwards 45 Coalflow Boiler manufactured by Hughes Edwards Heating Ltd.	The manufacturer's instructions which— (a) in the case of the installation instructions bear the reference II/02D/07-89; and (b) in the case of the user instructions bear the reference U1/02D/07-89.	The washed coals recommended in the manufacturer's instructions bearing the reference II/02D/07-89.
95.	The Hughes Edwards model 65 hot water boiler manufactured by Hughes Edwards Heating Limited.	The manufacturer's instructions bearing the reference "II/02D/11-90 and UI/02D/11-90".	Bituminous Coalflow pearls.
96.	Huntingdon 25 clear door (model number 7057) manufactured by Stovax Limited, Falcon Road, Sowerton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference "PM 249 Issue 1". A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 75 per cent open position.	Untreated dry wood.
97.	Huntingdon 25 tracery door (model number 7058) manufactured by Stovax Limited, Falcon Road, Sowerton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference "PM 249 Issue 1". A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 75 per cent open position.	Untreated dry wood.
98.	The Hwam Beethoven and Hwam Beethoven H (4.5 kW Nominal Thermal Output) fitted with mechanism	Euroheat Distributors (HBS) Limited's operation instructions referenced IN1141	Untreated dry wood.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	to prevent closure of the air wash/ secondary air control, manufactured by HWAM Heat Design, AS Nydamsvej 538362, Hørning, Denmark.	Ed B and dated November 2006.	
99.	The Hwam Mozart (4.5 kW Nominal Thermal Output) fitted with mechanism to prevent closure of the air wash/secondary air control, manufactured by HWAM Heat Design AS Nydamsvej 53 8362 Hørning Denmark.	Euroheat Distributors (HBS) Limited's operation instructions referenced IN1141 Ed B and dated November 2006.	Untreated dry wood.
100.	The Hwam Ravel (4.5 kW Nominal Thermal Output) fitted with mechanism to prevent closure of the air wash/secondary air control, manufactured by HWAM Heat Design AS Nydamsvej 53 8362 Hørning Denmark.	Euroheat Distributors (HBS) Limited's operation instructions referenced IN1141 Ed B and dated November 2006.	Untreated dry wood.
101.	The Hwam Vivaldi (4.5 kW Nominal Thermal Output) fitted with mechanism to prevent closure of the air wash/secondary air control, manufactured by HWAM Heat Design AS Nydamsvej 53 8362 Hørning Denmark.	Euroheat Distributors (HBS) Limited's operation instructions referenced IN1141 Ed B and dated November 2006.	Untreated dry wood.
102.	The Hwam 30 (4.5 kW Nominal Thermal	Euroheat Distributors (HBS) Limited's	Untreated dry wood.

Fireplace		Conditions	
	Output) fitted with	The fireplace must be installed, maintained and operated in accordance with the following specifications operation instructions	Fuels that must be used (other than authorised fuels)
	mechanism to prevent closure of the air wash/secondary air control manufactured by HWAM Heat Design AS Nydamsvej 53 8362 Hørning Denmark.	referenced IN1141 Ed B and dated November 2006.	
103.	The I.D.L, M and H incinerators, manufactured by the Incinerator Doctor.	The manufacturer's instructions dated February 1999 and bearing the reference "I.D.E.I.".	Paper, cardboard, untreated dry wood, foliage, floor sweepings and other waste containing no more than 20 per cent by weight of restauran and cafeteria waste and less than 5 per cent by weight of coated paper, plastic of rubber waste.
104.	Interfocos model Unilux-3 40 5kW wood burning insert and ECO 40 5kW wood burning room heater manufactured by Interfocos BV, Hallenstraat 17, NL-5531 AB, BLADEL, Netherlands.	The Unilux-3 40 Instruction Manual, document Version 01-326587 dated August 2009. The ECO 40 Instruction Manual, document Version 01-327332 dated October 2009.	Wood logs.
105.	The Intrepid II woodstove manufactured by Vermont Castings, Inc.	The manufacturer's instructions bearing the reference "AMENDED No. 20917C U.K. MAY 1990".	40 cm firewood that has been split, stacked and air-dried.
106.	The Jansen Design stove, using the five channel system, manufactured by	The manufacturer's instructions bearing the reference "CSC- JDS-OI dated 21/10/91".	Wood.

Fireplace		Conditions	
	Kakkelovnsmakeriet	The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	as.		
107.	The Jotul catalyst stove models 8TDIC and 12TDIC manufactured by Jotul Limited.	The manufacturer's instructions dated November 1995 bearing the following references:— (a) model 8TDIC: "JT8/001" and "J/S/001"; (b) model 12TDIC: "JT12/001" and "JT/S/001".	Wood.
108.	KOB Pyromat- ECO (KPM-ECO) models 35, 45, 55, 65, 75, 85, manufactured by Veissmann Limited, Hortonwood 30, Telford, Shropshire, TF1 7YP.	Instruction manual reference "ID 104646- D English" dated 01.01.2005 and instruction manual reference "ID: 104642-B English".	Wood logs (up to 0.5m) or off cuts of natural timber.
109.	KOB Pyromat- ECO (KPM-ECO) models 61, 81, 101 and 151 manufactured by Veissmann Limited, Hortonwood 30, Telford, Shropshire, TF1 7YP.	Instruction manual reference "ID 104646- D English" dated 01.01.2005 and instruction manual reference "ID: 104642-B English".	Wood logs (up to 1.0m) or off cuts of natural timber.
110.	KOB Pyrot (KRT) models 100, 150, 220, 300, 400 and 540 manufactured by Veissman Limited, Hortonwood 30, Telford, Shropshire, TF1 7YP.	Instruction manual reference "ID 104654- H English" dated 01.01.2005 and instruction manual reference "ID: 106811-H English".	Wood chips or pellets
111.	KOB Pyrtec (KPT) models 390, 530, 720, 950 and 1250 manufactured by Veissmann Limited, Hortonwood 30,	Instruction manual reference "ID 104661- F English" dated 01.01.2005 and instruction manual reference	Wood chips or pellets.

Fireplace		Conditions	
	Telford, Shropshire, TF1 7YP.	The fireplace must be installed, maintained and operated in accordance with the following specifications "ID: 105174-F English". Appliances must be fitted with	Fuels that must be used (other than authorised fuels)
		multicyclone dedusters.	
112.	KOB Pyromat-DYN (KPM-DYN) 45, 65 and 85 manufactured by Veissmann Limited, Hortonwood 30, Telford, Shropshire, TF1 7YP.	Instruction manual reference "ID 103689- L English" dated 01.01.2005 and instruction manual reference "ID: 103708-G English".	Wood logs (up to 0.5m) or off cuts of natural timber, wood chips and pellets.
113.	KWB TDS Powerfire 130, 240 and 300 manufactured by KWB – Kraft und Wärme aus Biomasse Gesellschaft mit Beschränkter Haftung (GmbH) of Industriestrasse 235, A-8321 St. Margarethen an der Raab, Austria.	KWB Instruction Manual reference BA TDS- 05.2008 and dated 14th May 2008.	Wood pellets or wood chips.
114.	KWB TDS Powerfire 150 manufactured by KWB – Kraft und Wärme aus Biomasse Gesellschaft mit Beschränkter Haftung (GmbH) of Industriestrasse 235, A-8321 St. Margarethen an der Raab, Austria.	The manufacturer's instructions dated August 2005, reference BA TDS-0805.	Wood pellets or wood chips
115.	Lin-ka H1500 Hot Water Boiler fitted with either a mono- cyclone (type LIN- KA 2000) or a multi-	Instruction manual reference "LIN-KA H 1500 Hot Water Manual/Ver. 2005/	Wood pellets of maximum diameter 8mm.

Fireplace		Cond	litions
	cyclone (type LIN-KA 3x2) manufactured by	The fireplace must be installed, maintained and operated in accordance with the following specifications Rev. 1.10" dated 27/01/2010.	Fuels that must be used (other than authorised fuels)
	LIN-KA Maskinfabrik A/S, Nylandsvej 38 DK-6940 Lem St. Denmark.	27/01/2010.	
116.	The Little Thurlow wood burning stove manufactured by Town and Country Fires, Pickering, North Yorkshire.	The manufacturer's instructions dated 30th June 2007, issue No 3.	Seasoned logs of less than 20 per cent moisture and of a maximum length of 350 mm.
117.	Little Wenlock Classic Wood Fuel Stove manufactured by Aga, Station Road, Ketley, Telford, Shropshire, TF1 5AQ.	Operating instructions dated 19th December 2008 reference N00471AXX Rev 001 DP081219.	Dry and split wood logs of a maximum length of 25 cm and a maximum diameter of 10 cm.
118.	Lotus Liva 1, Liva 2, Liva 3 and Liva 4G stoves manufactured by Lotus Heating Systems A/S, Agertoften 6, 5550 Langeskov, Denmark.	Instruction manual "Mounting and User Instructions Lotus- Liva series Stoves", version 4 dated January 2010.	Wood logs.
119.	Lotus Sola, Sola S, Sola M and Sola MST stoves manufactured by Lotus Heating Systems A/S, Agertoften 6, 5550 Langeskov, Denmark.	Instruction manual "Mounting and User Instructions Lotus- Sola series Stoves", version 2 dated January 2010.	Wood logs.
120.	The Løvenholm, Løvenholm Traditional, Løvenholm European and Løvenholm Pedestal Stoves manufactured by Hunter Stoves Limited, Unit 6, Old	Løvenholm Multifuel stove Installation and Operation manual version 06/09.	Untreated wood with a moisture content below 20 per cent.

Fireplace		Cond	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Mill Industrial Estate, Stoke Canon, Exeter, Devon, EX5 4RJ.		
121.	The Mawera FU-RIA models 110, 140, 180, 220, (UK) Limited of 31 Enterprise Industrial Park, Britannia Way, Lichfield, Staffordshire WS14 9UY.	The manufacturer's instructions dated 31st October 2002 and bearing the reference "098234-01".	Wood, wood products, forest residues, forest thinnings, melamine coated or uncoated MDF chipboard, plywood, or compound wood product.
122.	Mescoli PB28, PB35 and PB50, manufactured by MESCOLI CALDAIE S.rl. Caldaie – Termocucine, Via del Commercio, 285 41058 Vignola (MO) Italy.	Instruction and Installation Manual reference "SY315EVO P, C, B COMBIFIRE 2 PB28/35/50 BOILERS" edition 1.7 dated 1/2006.	Wood pellets following ÖNORM M 7135( <b>8</b> ) or DIN plus (DIN 51731)( <b>9</b> ).
123.	Monfort MK2 Stove manufactured by Franco Belge Staub, Staub Fonderie, Rue Orphee Bariscotte, BP 73, 59660 Merville, France.	Instruction manual reference "1295-3" dated 17th November 2009. The appliance must be fitted with a mechanical stop to prevent closure of the secondary air control beyond the 25 per cent open position.	Wood logs.
124.	Monterrey 6, York Midi and Serrano 5 manufactured by Broseley Fires Limited, Knights Way, Battlefield Enterprise	Instruction manual reference "09TJD" dated 01 2010. A system that prevents the closure of the	Wood logs.

This standard is issued by the Austrian Standards Institute. Copies may be obtained from that Institute at Heinestrasse 38, (8)

<sup>1020</sup> Vienna, Austria, http://www.austrian-standards.at. This standard is issued by the German Institute for Standardisation. Copies may be obtained from that Institute at Burggrafenstrasse, 6, 10787 Berlin, Germany, http://www.din.de. (9)

Fireplace		Conditions	
	Park, Shrewsbury, Shropshire, SY1 3AB.	The fireplace must be installed, maintained and operated in accordance with the following specifications secondary air flaps to less than 8mm open	Fuels that must be used (other than authorised fuels)
	Shiopshile, 511 574D.	position must be fitted.	
125.	The Morsø Owl 3410, 3420 and 3440 for wood burning manufactured by Morsø Jernstøberi A/S, DK-7900 Nykøbing, Mors, Denmark.	The manufacturer's instructions dated 1st January 2000, reference 72345600.	Untreated dry wood which has been split, stacked and air dried, or air dried wood briquettes.
126.	Morsø–Ø4 manufactured by Morsø Limited, Unit 7 – io centre, Valley Drive, Swift Valley, Rugby, Warwickshire, CV21 1TW.	For units manufactured after 1st February 2010, instruction manual references Ø-collection and 72000400, both dated 1st February 2010.	Wood logs.
127.	The Morsø 1400 series consisting of the 1412, and 1442 models manufactured by Morsø Jernstøberi A/ S DK-7900 Nykøbing, Mors, Denmark.	Installation and operation manual referenced 72146800 and dated 10.01.2008.	Wood logs with less than 20 per cent moisture.
128.	The Morsø 3100 series consisting of the 3112 and 3142 models manufactured by Morsø Jernstøberi A/ S DK-7900 Nykøbing, Mors, Denmark.	Installation and operation manual referenced 72311200 and dated 04.02.2008.	Wood logs with less than 20 per cent moisture.
129.	The Morsø 3400 Owl GB Series for wood burning manufactured by Morsø Jernstøberi A/S, Denmark.	The manufacturer's instructions dated 1st January 2000 and bearing the reference 72345600.	Untreated dry wood, which has been split, stacked and air dried, or air dried wood briquettes.
130.	The Morsø 6140 and 6148 models manufactured by Morsø Jernstøberi A/	Installation and operation manual referenced 72610400 and dated 04.09.2007.	Wood logs with less than 20 per cent moisture.

Fireplace		Conditions	
	S DK-7900 Nykøbing,	The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
131.	Mors, Denmark. The Nestor Martin Harmony Multi-Fuel Stove H23 (6 kW nominal thermal output), manufactured by Nestor Martin S A Finuick Nv Voie Axiale 5 B-5660 Couvin, Belgium.	Euroheat Distributors (HBS) Limited's operational instructions referenced IN1141 Ed B and dated November 2006.	Untreated dry wood.
132.	The Nestor Martin Harmony Multi- Fuel Stove H13 (3.5 kW nominal thermal output) and H33 (8 kW nominal thermal output) manufactured by Nestor Martin, S A Finuick Nv, Voie Axiale 5, B-5660 Couvin, Belgium.	Euroheat Distributors (HBS) Limited's operational instructions dated January 2007, reference IN1116 Edition D.	Untreated dry wood.
133.	The Nestor Martin Multi-Fuel Stove IT 13 (3.5 kW nominal thermal output) manufactured by Nestor Martin, S A Finuick Nv, Voie Axiale 5, B-5660 Couvin, Belgium.	Euroheat Distributors (HBS) Limited's operational instructions dated April 2007, reference IN1180 Edition C.	Untreated dry wood.
134.	The Nestor Martin Multi-Fuel Stove R33 and D33 (8 kW nominal thermal output) manufactured by Nestor Martin, S A Finuick Nv, Voie Axiale 5, B-5660 Couvin, Belgium.	Euroheat Distributors (HBS) Limited's operational instructions dated January 2007, reference IN1116 Edition D.	Untreated dry wood.
135.	The Nestor Martin R23 Stove (6 kW	Euroheat Distributors (HBS) Limited's	Untreated dry wood.

Fireplace		Cond	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	nominal thermal output), manufactured by Nestor Martin S A Finuick Nv Voie Axiale 5 B-5660 Couvin, Belgium.	operational instructions referenced IN1141 Ed B and dated November 2006.	
136.	The Nestor Martin Stanford Multi-Fuel Stove S13 (3.5 kW nominal thermal output), S33 and SP33 (8 kW nominal thermal output) manufactured by Nestor Martin, S A Finuick Nv, Voie Axiale 5, B-5660 Couvin, Belgium.	Euroheat Distributors (HBS) Limited's operational instructions dated January 2007, reference IN1116 Edition D.	Untreated dry wood.
137.	Nestor Martin Stanford Multi-Fuel Stove S13, S23 and SP23 (6 kW nominal thermal output) manufactured by Nestor Martin S A Finuick Nv, Voie Axiale 5, B-5660 Couvin, Belgium.	Euroheat Distributors (HBS) Limited's operational instructions referenced IN1141 Ed B and dated November 2006.	Untreated dry wood.
138.	The Nordist Waste Fired System, models 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22 and 23 manufactured in part by Nordfab A/S and in part by Danstoker A/S.	The manufacturer's instructions bearing the reference P.S.501 9.12.88.	Softwood shavings, hardwood shavings or sawdust.
139.	Ökofen Pellematic PE08, PE12, PE16, PE20, PE25 and PE32 manufactured by Ökofen of Auftragsbearbeitung	Ökofen operation instructions referenced PE/HB/001.E and with revision date 02/2007.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.

Fireplace			itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Gewerbepark 1, 4133 Niederkappel, Austria.		
140.	Ökofen Pellematic PE36, PE48 and PE56 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	Ökofen operation instructions referenced PBV 2000 CMP 1.4 (V2.31) and with revision date 03/2007.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.
141.	Ökofen Pellematic PEK12, PEK16, PEK20, PEK25 and PEK32 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	Ökofen operation instructions referenced PE/HB/001.E and with revision date 02/2007.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.
142.	Ökofen Pellematic PEK36, PEK48 and PEK56 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	Ökofen operation instructions referenced PBV 2000 CMP 1.4 (V2.31) and with revision date 03/2008.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.
143.	Ökofen Pellematic PES12, PES16, PES20, PES25 and PES32 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	Ökofen operation instructions referenced PE/HB/001.E and with revision date 02/2007.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.
144.	Ökofen Pellematic PES36, PES48 and PES56 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	Ökofen operation instructions referenced PBV 2000 CMP 1.4 (V2.31) and with revision date 03/2008.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.
145.	Ökofen Pellematic PESK12, PESK16, PESK20, PESK25 and	Ökofen operation instructions referenced	Wood pellets of maximum diameter

Fireplace		Conditions	
	PESK32 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	The fireplace must be installed, maintained and operated in accordance with the following specifications PE/HB/001.E and with revision date 02/2007.	Fuels that must be used (other than authorised fuels) 6 mm and maximum length of 4 cm.
146.	Ökofen Pellematic PESK36, PESK48 and PESK56 manufactured by Ökofen of Auftragsbearbeitung Gewerbepark 1, 4133 Niederkappel, Austria.	Ökofen operation instructions referenced PBV 2000 CMP 1.4 (V2.31) and with revision date 03/2008.	Wood pellets of maximum diameter 6 mm and maximum length of 4 cm.
147.	The Orchard Ovens models: FVR Speciale 80, 100, 110, 110 $\times$ 160 and 120; TOP Superiore 100 and 120; GR 100, 120, 140, 120 $\times$ 160, 140 $\times$ 160, 140 $\times$ 180 and 180; OT 100, 120, 140, 120 $\times$ 160, 140 $\times$ 160, 140 $\times$ 180 and 180 and the Valoriani Piccolo, all of which are manufactured by Valoriani of Via Caselli alla Fornace, 213,50066 Reggello, Firenze, Italy.	The manufacturer's instructions dated 25th October 2004, references: InstructionModel OOLinst.1 FVR 80 OOLinst.2 FVR 100 OOLinst.3 FVR 110 OOLinst.4 FVR 120 OOLinst.5 FVR 110 $\times$ 160 OOLinst.6 TOP 100 OOLinst.7 TOP 120 OOLinst.7 TOP 120 OOLinst.8 GR 100 and OT 100 OOLinst.9 GR 120 and OT 120 OOLinst.10GR 140 and OT 140 OOLinst.1 IGR 120 × 160 and OT 120 × 160	Untreated dry wood.

37

Fireplace		Cona	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
		InstructionModel           OOLinst.12GR 140 ×           160 and           OT 140 ×           160           OOLinst.13GR 140 ×           180 and           OT 140 ×           180 and           OT 140 ×           180 and           OT 140 ×           180           OOLinst.14GR 180           and OT           180           OOLinst.15Valoriani           Piccolo.	
148.	The Osier wood burning stove, manufactured by Reinhart von Zschock.	The manufacturer's instructions dated 30th September 1997 and bearing the reference "CSC/ OS/001".	Untreated dry wood.
149.	The Parkray- Coalmaster manufactured formerly by Radiation Parkray Limited and now by T. I. Parkray Limited.		Washed coal singles of nominal size 12.5 mm to 28 mm.
150.	The Parkray Coal-master II manufactured, both as an inset model and as a freestanding model, by T.I. Parkray Limited.	The manufacturer's instructions which— (a) in the case of the installation instructions for the inset model bear the reference "List No. 1048/June °83 8402"; (b) in the case of the installation instructions for the free standing model bear the date	Selected washed coal doubles and trebles or UCB (see entry 40).

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
		February 1984 and the reference "List No. 1058/ February 1984"; and (c) in the case of the user instructions for both models bear the reference "List No. 1049/ September 1983".	
151.	Pelletstar 10, 20, 30, 45 and 60 manufactured by HERZ Armaturen GmbH, Geschaftsbereich HERZ, Feuerungstechnik, A-8272 Sebersdorf 138, Austria.	Operating instructions dated November 2007 reference V2.2.	Wood pellets corresponding to ÖNORM M 7135(10) of diameter 6 mm.
152.	Portway 1 Stove manufactured by BFM Europe Limited, Trentham Lakes, Stoke on Trent, Staffordshire, ST4 4TJ.	Instruction manual reference 'Solid Fuel Stoves Manual issued – 20/08/2009 (291) 2'. The appliance must be used with a modification to the secondary air slide which prevents closure further than the 25mm from the left position.	Wood logs.
153.	Portway 2 and 3 Stoves manufactured by BFM Europe Limited, Trentham Lakes, Stoke on Trent,	Instruction manual reference 'Solid Fuel Stoves Manual issued – 20/08/2009 (291) 2'.	Wood logs.

<sup>(10)</sup> This standard is issued by the Austrian Standards Institute. Copies may be obtained from that Institute at Heinestrasse 38, 1020 Vienna, Austria, http://www.austrian-standards.at.

Fireplace		Cond	litions
	Staffordshire, ST4 4TJ.	The fireplace must be installed, maintained and operated in accordance with the following specifications The appliance must be used with a modification to the secondary air slide which prevents closure further than the 20mm from the left position.	Fuels that must be used (other than authorised fuels)
154.	Portway Inset Stove manufactured by BFM Europe Limited, Trentham Lakes, Stoke on Trent, Staffordshire, ST4 4TJ.	Instruction manual reference 'Solid Fuel Stoves Manual issued – 20/08/2009 (291) 2'. A modification of the secondary air control must be implemented such that the 20mm from left position is maintained during use. In addition the primary air control must be modified such that the minimum setting allows a bleed of air to pass through	Wood logs.
155.	The Quadra-Fire Cumberland Gap Freestanding Wood Burning Stove manufactured by Hearth & Home Technologies 1445 North Highway, Colville, WA 99114, USA.	The manufacturer's instructions dated 8th July 2003, reference 7006–186.	Dry cured untreated wood of maximum size 43.18 cm × 10.16 cm × 10.16 cm.
156.	The Quadra-Fire 2100 Millennium Freestanding Wood Burning Stove manufactured by Hearth & Home Technologies 1445 North Highway, Colville, WA 99114, USA.	The manufacturer's instructions dated 9th October 2003, reference 250–6931B.	Dry cured untreated wood of maximum size 38.1 cm × 10.16 cm × 5.08 cm.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
157.	The Quadra-Fire Yosemite Freestanding Wood Burning Stove manufactured by Hearth & Home Technologies 1445 North Highway, Colville, WA 99114, USA.	The manufacturer's instructions dated 4th June 2003, reference 7004–187.	Dry cured untreated wood of maximum size 38.1 cm × 10.16 cm × 5.08 cm.
158.	The RanHeat appliances models MSU150, MSU300, MSU500, WA150, WA300 and WA500, manufactured by Ranheat Engineering Limited.	The manufacturer's instructions dated July 1994 bearing the following reference:— (a) models MSU150, MSU300 and MSU500: "MSU150/500199 (b) models WA150, WA300 and WA500: "WA150/5001994	
159.	The RanHeat Boiler Type RHA 20 manufactured by RanHeat, Energy A/S.	The manufacturer's instructions dated 30th March 1988 and which bear the reference "RHGBEA 30388".	Hardwood and softwood shavings.
160.	The RanHeat Boiler Types RHA 160, 200 and 250, manufactured by RanHeat Energy GB Limited.	The manufacturer's instructions dated 30th March 1988 bearing the reference "RHGBEA 30388".	Hardwood and softwood shavings.
161.	The Rayburn Coalglo C-30 manufactured, both as an inset model and as a free-standing model, by Glynwed Appliances Limited.	The manufacturer's instructions which— (a) in the case of the inset model, bear the date 1st September 1981 and the reference "Code 510"; or	Selected washed coal doubles and trebles.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications (b) in the case	Fuels that must be used (other than authorised fuels)
		of the free- standing model, bear the date 1st December 1982 and the reference "Code 510F".	
162.	The Rayburn CB34 manufactured formerly by Glynwed Foundries Limited and now by Glynwed Appliances Limited.		Washed coal singles of nominal size 12.5 mm to 28 mm.
163.	The Rayburn Prince 76 manufactured formerly by Glynwed Domestic and Heating Appliances and now by Glynwed Appliances Limited.		Selected washed coal doubles and trebles.
164.	The Rayburn Prince 101 manufactured formerly by Glynwed Foundries Limited and now by Glynwed Appliances Limited.		Washed coal singles of nominal size 12.5 mm to 28 mm.
165.	The Rayburn Prince 301 (known formerly as the Rayburn Prince Model H) manufactured formerly by Glynwed Foundries Limited and now by Glynwed Appliances Limited.		Washed coal singles of nominal size 12.5 mm to 28 mm.
166.	Redfyre Kensal 20 Flat top (product code RF-KEN20M, Redfyre Kensal 33 Flat top (product	Instruction manual reference "PM 247 Issue 1" dated July 2008 and instruction manual "PM280	Untreated dry wood.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	code RF- KEN33M and RF-KEN33W) manufactured by Redfyre Cookers, Osprey Road, Sowton Industrial Estate, Exeter, Devon, EX2 7JG.	Issue 1" dated January 2009. A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 50 per cent open position.	
167.	The Resolute Acclaim woodstove manufactured by Vermont Castings, Inc.	The manufacturer's instructions bearing the reference "AMENDED No. 200 – 0908 U.K. OCTOBER 1991".	40 cm firewood that has been split, stacked and air-dried.
168	The Riley Nihot Woodchip Fired Air Heater type NMO 11 manufactured formerly by Clarke Chapman Limited International Combustion Division – Riley Unit and now by NEI International Combustion Limited, Riley Equipment.		Clean wood waste containing not more than 5 per cent sander dust.
169	Riva Plus Small (5kW), Midi (6.5kW) and Medium (8kW) stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM231 Issue 3 dated June 2009 and smoke control kit instruction manual reference PM402 Issue 1 dated November 2009. A permanent stop must be positioned to prevent closure of the	Wood logs.
		secondary air control below the 25 per cent open position.	

Fireplace			litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
170.	Riva Studio 1 Cassette (5kW) stove manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM274 Issue 2 dated October 2009 and smoke control kit instruction manual reference PM400 Issue 1 dated November 2009. A permanent stop must be positioned to prevent closure of the secondary air control below the 45 per cent open position and the primary air control fixed to prevent full closure to allow a bleed of air to enter the firebox at the base of the fuel bed.	Wood logs.
171.	Riva Studio 2 Cassette (8kW) stove manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM274 Issue 2 dated October 2009 and smoke control kit instruction manual reference PM400 Issue 1 dated November 2009. A permanent stop must be positioned to prevent closure of the secondary air control below the 25 per cent open position and the primary air control fixed to prevent full closure to allow a bleed of air to enter the firebox at the base of the fuel bed.	Wood logs.
172.	Riva Vision Small (5kW) and Riva	Instruction manual reference PM278	Wood logs.

Fireplace		Cond	itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Vision Midi (6.5kW) Multifuel stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate,	Issue 2a dated October 2009 and smoke control kit instruction manual reference PM401 Issue 1 dated January 2010.	
	Exeter, Devon, EX2 7LF.	A permanent stop must be positioned to prevent closure of the secondary air control below the 50 per cent open position.	
173.	Riva Vision Medium (8kW) Multifuel stove manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM278 Issue 2a dated October 2009 and smoke control kit instruction manual reference PM401 Issue 1 dated January 2010.	Wood logs.
		A permanent stop must be positioned to prevent closure of the secondary air control below the 25 per cent open position.	
174.	Riva 40 Cassette 4.9kW stove manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM235 Issue 2 dated August 2009 and smoke control kit instruction manual reference PM375 Issue 2 dated January 2010. A permanent stop	Wood logs.
		must be positioned to prevent closure of the secondary air control below the 50 per cent open position.	
175.	Riva 40 Freestanding, Riva 40 Avanti,	Instruction manual reference PM226 Issue	Wood logs.

Fireplace		Cond	itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Riva 40 Avanti Midi and Riva 40 Avanti Highline 4.9kW stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	2 dated August 2009 and smoke control kit instruction manual reference PM375 Issue 2 dated January 2010. A permanent stop must be positioned to prevent closure of the secondary air control below the 50 per cent open position.	
176.	Riva 55 Cassette, Riva 66 Cassette and Riva 66 Avanti Cassette stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM235 Issue 2 dated August 2009 and smoke control kit instruction manual reference PM375 Issue 2 dated January 2010. A permanent stop must be positioned to prevent closure of the secondary air control below the 50 per cent open position and the primary air control fixed to allow a bleed of air to enter the firebox from underneath the grate.	Wood logs.
177.	Riva 55 Avanti Midi and Riva 66 Freestanding 8kW stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM226 Issue 2 dated August 2009 and smoke control kit instruction manual reference PM375 Issue 2 dated January 2010. A permanent stop must be positioned to prevent closure of the secondary air control below the 50	Wood logs.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
		per cent open position and the primary air control fixed to allow a bleed of air to enter the firebox from underneath the grate.	
178.	The SE60 Coalburner Stove manufactured by Jetmaster Fires Limited.	The manufacturer's instructions which— (a) in the case of the installation instructions bear the reference "SE60/1 8/84"; and (b) in the case of the user instructions bear the reference "SE60/2 8/84".	UCB.
179.	Scan Andersen 4-5 manufactured by Krog Iversen & Co. A/S DK-5492 Vissenbjerg, Denmark.	Instruction manual with title "Scan Andersen 4-5" and dated "15/11/07" and instructions for installation referenced "Edition 09/05-GB". A permanent stop must be in place on the secondary air inlet to prevent closure beyond 20 mm.	Untreated dry wood.
180.	Schmid UTSK 180, 240, 300, 360, 450, 550, 700, 900, 1200 and 1600 manufactured by Schmid AG Wood Firing Systems, PO Box 42, CH-8380 Eschikon, Switzerland.	Instruction manual "UTSK – ABC.22 – AME – S – PPU" dated 25.09.2008, where "ABC" is model number i.e. 180, 240, 300, 360, 450, 550, 700, 900, 1200, 1600.	Wood pellets or wood chips following CEN/ TS 14961:2005(11).

<sup>(11)</sup> This standard is issued by the European Committee for Standardisation (CEN). Copies may be obtained from CEN at Avenue Marnix 17, B-1000, Brussels, Belgium, http://www.cenorm.be.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
181.	Schmid UTSL 30, 40, 50, 65, 80, 110 and 150 manufactured by Schmid AG Wood Firing Systems, PO Box 42, CH-8380 Eschikon, Switzerland.	Instruction manual reference "Operating Manual Wooden Chips and Pellets Plant. Lignumat UTSL" dated 23.12.2004.	Wood pellets or wood chips following CEN/ TS 14961:2005.
182.	Schmid UTSP 180, 240 and 300 manufactured by Schmid AG Wood Firing Systems, PO Box 42, CH-8380 Eschikon, Switzerland.	Instruction manual "UTSK – ABC.22 – AME – S – PPU" dated 25.09.2008, where "ABC" is model number i.e. 180, 240, 300.	Wood pellets following CEN/TS 14961:2005.
183.	Schmid UTSR 150, 180, 240 and 300 manufactured by Schmid AG Wood Firing Systems, PO Box 42, CH-8380 Eschikon, Switzerland.	Instruction manual "UTSK – ABC.22 – AME – S – PPU" dated 25.09.2008, where "ABC" is model number i.e. 150, 180,	Wood pellets or wood chips following CEN/ TS 14961:2005.
184.	The Silent Glow Incinerator, models CCD 450, 600 and 750 manufactured by Silent Glow Incinerators Ltd.	The manufacturer's instructions dated May 1989.	Solid waste of the types specified in the manufacturer's instructions dated May 1989.
185.	The Solid Fuel Ductair Unit manufactured by Radiation Limited.		
186.	The Spacewarmer B200 manufactured by Clearair Limited.	The manufacturer's instructions bearing the reference "B200/ DEC 83". The fireplace must not be used to burn chipboard or plastic coated chipboard unless an afterburner, supplied by the manufacturer of the fireplace and	Hardwood or softwood offcuts; a mixture of offcuts (hardwood or softwood) and sawdust with no more than 50 per cent of the mixture being sawdust; chipboard offcuts; or plastic coated chipboard offcuts.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications capable of producing 50 megajoules of heat per hour, has been	Fuels that must be used (other than authorised fuels)
187.	The Spacewarmer B500 manufactured by Clearair Limited.	fitted to the fireplace. The manufacturer's instructions bearing the reference "B500/ DEC 83".	Hardwood or softwood offcuts.
188.	The Spänex Wood Fired Air Heater (types UL50, UL75 and UL100 only) manufactured by Spänex Sander GmbH.		Clean wood waste containing not more than 5 per cent sander dust and not more than 1 per cent plastic contamination.
189.	Stockton 5 Canopy (model number 7160) manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference "PM 176- Issue 4". A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 50 per cent open position.	Untreated dry wood.
190.	Stockton 5 Flat top (model number 7119) manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference "PM 176- Issue 4". A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 50 per cent open position.	Untreated dry wood.
191.	Stockton 5 Midline (model number 7133) manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference "PM 176- Issue 4". A permanent stop must be in place on the secondary air inlet to prevent closure	Untreated dry wood.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications beyond the 50 per cent open position.	Fuels that must be used (other than authorised fuels)
192.	Stockton 3 Flat top (product code 7118), Stockton 4 flat top (product code 7101 and 7102), Stockton 5 Flat top (product code 7127), Stockton 5 midline (product code 7130), Stockton 6 Flat top (product codes 7100 and 7162), Stockton 6 Highline (product code 7117) and Stockton 7 Flat top (product codes 7120 and 7163) manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual references "PM227 ENG Issue 2" dated July 2008 and instruction manual "PM271 Issue 2" dated January 2009. A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 50 per cent open position.	Untreated dry wood.
193.	Stockton 7 Inset Convector (product codes 7125F and 7125C) manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference "PM230 Issue 1" dated May 2008 and instruction manual "PM281 Issue 1" dated January 2009. A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 50 per cent open position.	Untreated dry wood.
194.	The Talbott 500 Hot- air Heater (afterburn model) manufactured by Talbott's Heating Limited.	The manufacturer's instructions dated January 1st 1983, and bearing the reference A10000.	Wood off-cuts, woodwaste, pallets, chipboard, plastic covered chipboard (th plastic content of the covering being not more than 1 per cent

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications The afterburn cycle must last not less than	Fuels that must be used (other than authorised fuels) by weight), cardboard or paper.
		25 minutes and must come into operation each time the loading door is opened.	
195.	The Talbott combustion unit models C1, C2, C3 and C4 manufactured by Talbott's Heating Limited.	The manufacturer's instructions dated August 1995 bearing the reference "Issue C1000/C/Range".	Chipboard or wood shavings, forestry chips or paper briquettes.
196.	The Talbott Combustion Units, models CM1, CM2, CM3 and CM4, manufactured by Talbott's Heating Limited.	The manufacturer's instructions dated August 1997 and bearing the reference "Issue: CM897".	Woodwaste, pallets, medium density fibreboard, melamine faced chipboard, cardboard, paper or untreated and airdried wood offcuts.
197.	The Talbott Energy Saving Wood Waste Burning Automatic Warm Air Heaters, models T1.5/A, T3/ A, T5/A and TM/ A manufactured by Talbotts Heating Limited.	The manufacturer's instructions bearing the reference "T/A JANUARY 1990".	Hardwood or softwood shavings or sawdust.
198.	The Talbott Energy Saving Wood Waste Burning Automatic Hot Water Heaters, models T1.5/AB, T3/ AB, T5/AB and TM/ AB, manufactured by Talbott's Heating Limited.	The manufacturer's instructions dated October 1993 and bearing the reference "Issue: A1001".	Hardwood or softwood shavings or sawdust.
199.	The Talbott Heating models T75, T150, T300, D250B, D500B and D700B, manufactured by	The manufacturer's instructions dated 1st January 1995 bearing the following references:—	(a) Models T75, T150 and T300: wood offcuts, woodwaste pallets, chipboard,

Fireplace			litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	Talbott's Heating Limited.	(a) models T75, T150 and T300: "gen/sttech"; (b) models D250B, D500B and D700B: "Gen/ Tech".	<ul> <li>plastic coated chipboard, cardboard or paper;</li> <li>(b) models D250B, D500B and D700B: hardwood or softwood offcuts chipboard, plastic coated chipboard or cardboard.</li> </ul>
200.	The Talbott Pirojet P150 Heater manufactured by Talbott's Heating Limited.	<ul> <li>The manufacturer's instructions dated February 1987 and which bear the reference "No P150-2-87".</li> <li>When the fireplace is used to burn chipboard and plastic coated chipboard, an afterburner which is supplied with the fireplace and which must be capable of continuously producing 20 megajoules of heat per hour must be used.</li> <li>The fireplace must not be used to burn sawdust in bulk.</li> </ul>	Hardwood or softwood offcuts, sawdust, chipboard or plastic coated chipboard.
201.	The Talbott Pirojet P300 Heater manufactured by Talbott's Heating Limited.	The manufacturer's instructions dated February 1987 and which bear the reference "No P300-2-87". When the fireplace is used to burn 52	Hardwood or softwood offcuts, sawdust, chipboard or plastic coated chipboard.

Fireplace		Cond	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
		chipboard and plastic coated chipboard, an afterburner which is supplied with the fireplace and which must be capable of continuously producing 40 megajoules of heat per hour must be used. The fireplace must	
		not be used to burn sawdust in bulk.	
202.	The Talbott Pirojet P600 Heater manufactured by Talbott's Heating Limited.	The manufacturer's instructions dated December 1986 and which bear the reference "P600-12-86".	Hardwood or softwood offcuts, sawdust, chipboard or plastic coated chipboard.
		When the fireplace is used to burn chipboard and plastic coated chipboard, an afterburner which is supplied with the fireplace and which must be capable of continuously producing 75 megajoules of heat per hour must be used.	
		The fireplace must not be used to burn sawdust in bulk.	
203.	The Talbott T5-1M Automatic Heater manufactured by Talbott's Heating Ltd.	The manufacturer's instructions bearing the reference Jan. 89 T5-A-1-89.	Softwood shavings, hardwood shavings or chipboard dust.
204.	The Talbott Warm Air Heaters Down Firing range models	The manufacturer's instructions bearing	Hardwood or softwood offcuts, chipboard, plastic

Fireplace			itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	D250, D500 and D700 manufactured by Talbotts Heating Limited.	the reference "MAY 1991 Ref No: D257".	coated chipboard or cardboard.
205.	The Trash X incinerator, models TX25, TX35, TX50, TX35L and TX50L, manufactured by Roscoe Fabrications Limited.	The manufacturer's instructions dated 1998 and bearing the reference "TX/1998".	Paper, card, untreated dry wood and cotton waste.
206.	The Trianco "Coal King" Boiler manufactured by Trianco Redfyre Limited.	The manufacturer's instructions dated May 1983 and which— (a) in the case of the installation instructions, bear the reference '47664'; and (b) in the case of the user instructions, bear the reference '47665'.	Selected washed coal doubles or UCB.
207.	The Triancomatic 45 boiler manufactured by Trianco Redfyre Limited.	The manufacturer's instructions dated September 1989 and which— (a) in the case of the installation instructions bear the reference "No. 44359"; and (b) in the case of the user instructions bear the reference "No. 44358".	The washed coals recommended in the manufacturer's user instructions.
208.	The Triancomatic 60 boiler manufactured by Trianco Redfyre Limited.	The manufacturer's instructions dated 24th July 1985 and which—	The washed coals recommended in the manufacturer's user

Fireplace		Cond	litions
		The fireplace must be installed, maintained and operated in accordance with the following spacifications	Fuels that must be used (other than authorised fuels)
		specifications(a) in the case of the installation instructions bear the reference "No. 45576"; and (b) in the case of the user instructions bear the reference "No. 45574".	instructions: reference "No. 45574".
209.	Triancomatic 90 boiler manufactured by Trianco Redfyre Limited.	The manufacturer's instructions dated July 1987 and which— (a) in the case of the installation instructions bear the reference "No 46576"; and (b) in the case of the user instructions bear the reference "No 46574".	The washed coals recommended in the manufacturer's user instructions.
210.	The Triancomatic 140 boiler manufactured by Trianco Redfyre Limited.	The manufacturer's instructions dated November 1986 and which— (a) in the case of the installation instructions bear the reference "No 48375"; and (b) in the case of the user instructions bear the reference "No. 48374".	The washed coals recommended in the manufacturer's user instructions.
211.	The Triancomatic T.80 manufactured formerly by Trianco Limited and now by Trianco Redfyre Limited.		Either washed coal pearls of nominal size 6 mm to 16 mm, or washed coal singles of nominal size 12.5 mm to 28 mm.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
212.	The Trianco TGB17 manufactured formerly by Trianco Limited and latterly by Trianco Redfyre Limited.		Either washed coal pearls of nominal size 6 mm to 16 mm, or washed coal singles of nominal size 12.5 mm to 28 mm.
213.	The "Turbo" Heat, models 1000 and 1200 manufactured by CBR Engineers Limited.	The manufacturer's instructions bearing the reference "CBR "TURBO" HEAT 1000 TO 1200 1990".	Hardwood or softwood offcuts, chipboard offcuts or plastic coated chipboard offcuts.
214.	Turbomatic 28, Turbomatic 35, Turbomatic 48, 55, manufactured by Fröling Heizkessel- und Behälterbau Gesm. B. H, Industriestraβe 12, A-4710 Grieskirchen, Austria.	Installation manual reference M 060 01 03 dated 11/2003. Operating manual 99229a dated August 2002.	Wood pellets of 6 mm diameter and a moisture content below 10 per cent.
215.	Turbomatic 85, Turbomatic 100 and Turbomatic 110, manufactured by Fröling Heizkessel- und Behälterbau Gesm. B. H, Industriestraβe 12, A-4710 Grieskirchen, Austria.	Installation manual reference M 060 01 03 dated 11/2003. Operating manual 99229a dated August 2002.	Wood pellets of 6 mm diameter and a moisture content below 10 per cent.
216.	Twinheat CS150i manufactured by Twinheat, Nørreevangen 7, DK-9631, Denmark.	Operating instructions dated 17th December 2008 reference Version 6.0.03.	Wood pellets of a maximum length of 30 mm and diameter of 6 mm and conforming to CEN/ TS 14961:2005( <b>12</b> ).
217.	The Type USP wood pellet-fired boilers, model numbers	The manufacturer's instructions dated 28th July 2003,	Wood pellets.

<sup>(12)</sup> This standard is issued by the European Committee for Standardisation (CEN). Copies may be obtained from CEN, Avenue Marnix 17, B-1000, Brussels, Belgium, http://www.cenorm.be.

Fireplace		Conditions	
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	USP-10, 15, 20, 25 and 30, manufactured by KWB – Kraft und Wärme aus Biomasse Gesellschaft mit beschränkter Haftung (GmbH) of Industriestrasse 235, A- 8321 St. Margarethen an der Raab, Austria.	reference BA-USP 0703.	
218.	The Type USV wood pellet- and wood chipfired boilers, model numbers USV-15, 25, 30, 40, 50, 60, 80 and 100, manufactured by KWB – Kraft und Wärme aus Biomasse Gesellschaft mit beschränkter Haftung (GmbH) of Industriestrasse 235, A-8321 St. Margarethen an der Raab, Austria.	The manufacturer's instructions dated August 2003, reference BA-USV 0803.	Wood pellets or wood chips.
219.	The WTH 150 and WTH 200 boilers manufactured by Hargassner Gesellschaft mit beschrankter Haftung (GmbH), Gunderding 8, A04952, Weng, Austria.	The manufacturer's installation manual version 91 for Large Capacity Boiler WTH 150-200 (reference BA GK V90b 0309).	Wood chip or wood pellets.
220.	Westfire Uniq 15, 16 and 20 (also known as WF UNIQ 15, 16 and 20) manufactured by Westfire Tømrervej 3 DK-6800 Varde Denmark.	Installation and operating instructions referenced: WF15 – WF16 – WF20 dated 2007 along with supplementary instructions reference	Untreated dry wood.

Fireplace		Cona	litions
		The fireplace must be installed, maintained and operated in accordance with the following specifications 01wfuk.2007 and dated 2007.	Fuels that must be used (other than authorised fuels)
		A permanent stop must be in place on the secondary air inlet to prevent closure beyond 50 mm.	
221.	Windhager Bio Win 100, 150, 210 and 260 manufactured by Windhager Zentralheizung GmbH, Anton- Windhager-Str. 20, A-5201 Seekirchen bei Salzburg, Austria.	Instruction manual referenced "0916197/00" and dated "05/2005".	Wood pellets.
222.	Windhager Fire Win 90 and 120 manufactured by Windhager Zentralheizung GmbH, Anton- Windhager-Str. 20, A-5201 Seekirchen bei Salzburg, Austria.	Instruction manual referenced "092125/00" and dated "08/2007".	Wood pellets.
223.	The Wood Chip Fired Air Heater manufactured formerly by Air Plants Limited and now by Air Plant (Sales) Limited.		Clean wood waste.
224.	The Wood Stone Ovens, models WS-MS-4-W (Mt. Chuckanut), WS- MS-5-W (Mt. Adams), WS-MS-6-W (Mt. Baker) and WS-MS-7- W (Mt. Rainier), manufactured by the Wood Stone Corporation, USA.	The manufacturer's instructions dated 8th September 1998 and bearing the reference "BPWS version 1".	Untreated dry wood.
225.	The Wood Waste Technology Heater	The manufacturer's instructions dated	Medium density fibreboard, melamine

Fireplace		Cona	itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)
	model WT5 manufactured by Wood Waste Technology Limited.	16th February 2009, reference WT5_v2.	faced chipboard, untreated wood offcuts, air-dried medium density fibreboards, air- dried melamine faced chipboard, untreated and air-dried wood offcuts.
226.	The Wood Waste Technology Heater, models WT10 and WT15, manufactured by Wood Waste Technology Limited.	The manufacturer's instructions dated 19th January 2005, reference WT10 and WT15.	Medium density fibreboard, melamine faced chipboard, untreated wood offcuts, air-dried medium density fibreboards, air- dried melamine faced chipboard, untreated and air-dried wood offcuts.
227.	The Worcester Centair 40 Solid Fuel Warm Air Heater manufactured by Worcester Engineering Co. Limited.	The manufacturer's instructions which— (a) in the case of installation instructions bear the reference "BC40.1.2. July 1983"; and (b) in the case of operating and maintenance instructions, bear the reference "BC40.OM2 July 1983".	UCB (see entry 40).
228.	The Worcester Coalstream 17.5 kw underfeed stoker manufactured by Worcester Engineering Company Limited.	The manufacturer's instructions dated 1st August 1985 and which— (a) in the case of the installation instructions bear the reference	The washed coals recommended in the manufacturer's user instructions: reference "No. ZKLIT 139".

Fireplace			itions
		The fireplace must be installed, maintained and operated in accordance with the following specifications "No. ZKLIT 140"	Fuels that must be used (other than authorised fuels)
		and (b) in the case of the user instructions bear the reference "No. ZKLIT 139"	
229.	Xeoos 5kW stove (versions Natur, Style, Harmony, Pur, Classic, Elegance and Stone) and Xeoos 8kW stove (versions Basic, Pur, Classic, Elegance, Stone and Air) manufactured by Specht Ofensysteme GmbH, Banhofstrasse 2, 35116 Hatzfield, Germany.	Installation manual reference "Operating and Installation Instructions Xeoos 5kw/8kw Model 2008", reference: Revisions – Index 01/08 Fassung January 2008.	Wood logs conforming to DIN 51731( <b>13</b> ).
230.	Yeoman Exmoor Multifuel Flat Top and Multifuel Low Canopy (4.9kW) Stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM 184 Issue 3 dated February 2008 and smoke control kit instruction manual reference PM403 Issue 1 dated January 2010. A permanent stop must be positioned to prevent closure of the secondary air control below the 60% open position and a system that prevents full closure of the primary air controls.	Wood logs.
231.	Yeoman Exe Multifuel Flat Top 1 Door, Flat Top 2 Door,	Instruction manual reference PM 184 Issue 3 dated February	Wood logs.

<sup>(13)</sup> This standard is issued by the German Institute for Standardisation. Copies may be obtained from that Institute at Burggrafenstrasse 6, 10787 Berlin, Germany, http://www.din.de.

Fireplace		Conditions		
		The fireplace must be installed, maintained and operated in accordance with the following specifications	Fuels that must be used (other than authorised fuels)	
	Low Canopy 1 Door and Low Canopy 2 Door (4.9kW) Stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	2008 and smoke control kit instruction manual reference PM403 Issue 1 dated January 2010. A permanent stop must be positioned to prevent closure of the secondary air control below the 60% open position and a system that prevents full closure of the primary air controls.		
232.	Yeoman Devon Multifuel Flat Top 1 Door, Flat Top 2 Door, Low Canopy 1 Door, Low Canopy 2 Door, High Canopy 1 Door and High Canopy 2 Door (9kW) Stoves manufactured by Stovax Limited, Falcon Road, Sowton Industrial Estate, Exeter, Devon, EX2 7LF.	Instruction manual reference PM 184 Issue 3 dated February 2008 and smoke control kit instruction manual reference PM403 Issue 1 dated January 2010. A permanent stop must be positioned to prevent closure of the secondary air control below the 50% open position and a system that ensures a gap of 1mm for bleed of primary air when the spin wheels are rotated to their full closed positions.	Wood logs.	
233.	6 Series (7Kw) Stoves: Flatford 6, Barrington 6, Petworth 6, Hampstead 6, Alpine 6 (also sold as: Sunbeam 6, Dakota 6, Providence 6) and the Chelsea 6 (also	Chesneys 6 series instruction manual reference "CH6K-V4" dated 7th December 2009. The appliance must be fitted with a	Wood logs.	

Fireplace		Conditions	
	sold as: Wellington 6, Guernsey 6, Belgravia 6) manufactured by Chesneys, 194-200 Battersea Park Road, London, SW1 14ND.	The fireplace must be installed, maintained and operated in accordance with the following specifications mechanical stop to prevent closure of the air control beyond the 10mm open position.	Fuels that must be used (other than authorised fuels)
234.	4 Series (4.6kW) Stoves: Flatford 4, Hampstead 4, Alpine 4 (also sold as: Sunbeam 4, Dakota 4, Providence 4), Pacific 4 (also sold as: Milan 4, Murano 4, Apollo 4), Chelsea 4 (also sold as: Wellington 4, Guernsey 4, Belgravia 4), manufactured by Chesneys, 194-200 Battersea Park Road, London, SW1 14ND.	Chesneys 4 series instruction manual reference "CH4K-V4" dated 7th December 2009. The appliance must be fitted with a mechanical stop to prevent closure of the air control beyond the 34mm open position.	Wood logs.
235.	100 SE Smoke Exempt Woodburning Stove manufactured by by ESSE Engineering Limited, Ouzledale Foundry, Long Ing, Barnoldswick, Lancashire, BB18 6BN.	Instruction manual referenced "100SE Issue 1" dated "03/09". A permanent stop must be in place on the secondary air inlet to prevent closure beyond the 50 per cent open position.	Untreated dry wood with a maximum moisture content of 20 per cent maximum length of 200 mm and maximum width or diameter of 120 mm.
236.	125 SE manufactured by ESSE Engineering Limited, Ouzledale Foundry, Long Ing, Barnoldswick, Lancashire, BB18 6BN.	Instruction manual reference "Esse125SE Issue 1" dated 08 2009. All appliances must be fitted with a mechanical stop to prevent closure	Wood logs.

Fireplace	Conditions	3
	and operated in use	els that must be d (other than horised fuels)

## **EXPLANATORY NOTE**

## (This note is not part of the Order)

This Order, which extends to Scotland only, makes provision for exemption from the prohibition, under section 20 of the Clean Air Act 1993, on the emission of smoke in smoke control areas.

The Order exempts those fireplaces described in the Schedule where they comply with the conditions specified in that Schedule.

The Order revokes and re-enacts the Smoke Control Areas (Exempt Fireplaces) (Scotland) Order 2009 (S.S.I. 2009/214). It also provides for additional fireplaces to be exempt. The additional entries in the Schedule are: 6; 14 to 16; 21; 25 to 27; 30 and 31; 33; 37; 45 and 46; 55 to 58; 60 to 62; 72 to 78; 82 to 84; 91; 104; 108 to 112; 115; 118 to 120 (other than the Løvenholm); 122 to 124; 126; 152 to 154; 169 to 177; 180 to 183; 219; 229 to 234; and 236. Additionally, an amendment has been made to the conditions applying to entry 70.

An exemption from the requirements of section 20 of the Clean Air Act 1993 does not confer exemption under any other statutory regime which may be applicable, and the burning of waste may be subject to other controls such as licensing under the Waste Management Licensing Regulations 1994 (S.I. 1994/1056) or permitting under the Pollution Prevention and Control (Scotland) Regulations (S.S.I. 2000/323).

No Regulatory Impact Assessment has been prepared for this instrument as it has no impact on the costs of business.